

Workshop Wizard Handbook

Microfluidics Lab Routine Maintenance

Chores

1. *Check and replenish paper towels in dispensers* - Paper towels are stocked in brown paper packages on the shelves along the wall by the entrance.
2. *Check and replenish gloves* - Check if any glove boxes are about to run out. If they are, open up the next one on top of the stack and add a new box of gloves to the bottom of the stack. - Make sure there are both nitrile and latex gloves to use. - Gloves are stocked on the shelves along the wall by the entrance, as well as above the vacuum furnace.
3. *Tidy up bench spaces* - Properly dispose of sharps and put away tools/supplies.
4. *Sweep and mop* - Walkways and under benches - Use the general maintenance cart located in the hallway outside the lab. Cleaner is stored in the cabinet under the sink.
5. *Check and replenish hazardous waste labels*
6. *Check sharps containers* - If full, tape off the top and place in the hazardous waste bin.
7. *Check glass waste bin* - If full, seal and tape off the top.
8. *Make sure all cabinets are locked*
9. *Check and replenish Kim wipes at every station* - Kim wipes are stocked on the shelves along the wall by the entrance.

To be continued

Last updated 5:26 PM Daniel Huang

From:
<https://bpm-wiki.cnsi.ucsb.edu/> - **NSF BioPACIFIC MIP Wiki**

Permanent link:
https://bpm-wiki.cnsi.ucsb.edu/doku.php?id=workshop_wizard_handbook&rev=1579224534

Last update: **2020/01/17 01:28**

