# **UV Curing Oven**

APM LED UV-Cu	ıbe		
×			
Tool Type: UV Curing Over			
Location: Elings 2436			
Manufacturer: APM			
<b>Principal Scientist</b>			
Juan Manuel Urueña			
jmuruena@ucsb.edu			

#### **About**

The UV curing oven is located in Elings Hall 2436.

Some Carbon Resins used in the Form 2 3D printer can benefit from post process curing. Each resin has a specific hardening curve which can be found within the reference material which will indicate the ideal time and temperature to be set on the APM UV curing oven.

## **Detailed Specifications**

LED source: 365 nm

<b>Tray Position</b>	<b>Power Setting</b>
top	32 mW/cm <sup>2</sup>
middle	17 mW/cm <sup>2</sup>
bottom	12 mW/cm <sup>2</sup>

### **Safety Concerns**

- \* Allow at least half an hour for IPA to evaporate before placing part in FormCure
- \* Allow time for the FormCure to cool off before removing parts
- \* Do not operate FormCure with lid open

#### **Operating Proceduces**

1. Any part to be cured needs to be washed in the FormWash with IPA BEFORE being placed in the form cure.

- 2. Supports can be removed before or after curing process.
- 3. Wait 30 minutes after washing to allow all remaining IPA to evaporate
- 4. Check the reference material for selected resin to determine ideal time and temperature for curing
- 5. Use the dial on the front of the FormCure to set time and temperature
- 6. Place part within the FormCure→ press start.

#### **Reference Documentation**

APM LED UV-Cube II User Manual

From:

https://bpm-wiki.cnsi.ucsb.edu/dokuwiki/ - NSF BioPACIFIC MIP Wiki

Permanent link:

https://bpm-wiki.cnsi.ucsb.edu/dokuwiki/doku.php?id=amp\_led\_uv-cube\_ii

Last update: 2024/10/10 17:08

