

# Stratsys F270 FDM 3D Printer



| Stratsys F270 FDM 3D Printer                 |                        |
|----------------------------------------------|------------------------|
| Tool Type: "F3D printer"                     |                        |
| Location: "Innovations Workshop"             |                        |
| Supervisor                                   | Tool Lead              |
| David Bothman                                | "Andrew Furst"         |
| (805) 893-4125                               | (801) 928-8869         |
| bothman@cnsi.ucsb.edu                        | "andrewfurst@ucsb.edu" |
| Description: "FDM duel extrusion 3D printer" |                        |
| Manufacturer: "Stratasys"                    |                        |

## About

The F270 is a fast and precise filament fed fusion deposition printer. Typically set up with ABS and a propitiatory Ecoworks soluble filament. Requires heated sodium hydroxide bath to remove support material.

## Detailed Specifications

Build area: 308 x 254 x 308 mm  
Duel extrusion 3D printer (build and support material)  
capable of printing PLA, ABS, ASA, QSR  
.254 mm min layer thickness  
tolerance of +/- .200 mm

4 spool bay

---

## Safety Concerns

Insert Text Here!

---

## Operating Procedures

Insert Text Here!

---

## Reference Documentation

[bp\\_fdm\\_supportremoval.pdf](#)

[f123\\_series\\_operation\\_and\\_maintenance\\_rev\\_a.pdf](#)

[sds\\_ecoworks\\_msds.pdf](#)

[stratasys\\_f123\\_series\\_user\\_manual\\_.pdf](#)

GrabCAD Tips, Guides, and FAQs <https://help.grabcad.com/category/193-tips-guides-and-faqs>

Changing F270 filament <https://www.youtube.com/watch?v=LFdPajgFTDk>

Printing using the F270 <https://www.youtube.com/watch?v=t8KyZYLnGIk>

## Training Documentation

[notes\\_on\\_post\\_processing\\_f270\\_parts.pdf](#)

Maintenance Schedule (see user maintenance page 80):

- Clean oven chamber weekly
- Clean platen weekly
- Inspect, wipe, and clean tip wipe assemblies monthly
- Clean exterior of printer as needed
- Clean touchscreen as needed

[notes\\_on\\_post\\_processing\\_f270\\_parts.pdf](#)

From:

<https://bpm-wiki.cnsi.ucsb.edu/dokuwiki/> - **NSF BioPACIFIC MIP Wiki**

Permanent link:

[https://bpm-wiki.cnsi.ucsb.edu/dokuwiki/doku.php?id=stratsys\\_f270&rev=1594664085](https://bpm-wiki.cnsi.ucsb.edu/dokuwiki/doku.php?id=stratsys_f270&rev=1594664085)

Last update: **2020/07/13 18:14**

